








# UNIVERSAL RECEPTACLE

SURFACE MOUNT INSTALLATION INSTRUCTIONS

MOUNTING KIT (SOLD SEPARATELY)	TOOLS NEEDED				
	 pencil   3/16", 3/8" & 1/2" drill bits for concrete	 hammer drill	 steel wire brush  1/4" punch	 hammer  7/32" hex bit or key	

**STEP BY STEP** FOR ALL SURFACE MOUNTED UNIVERSAL RECEPTACLES (SECTION VIEW SHOWN)



### 1 Mark hole location


- Place receptacle in desired location. Mark center of mounting hole locations in base with a pencil.



### 2 Drill hole

- Use hammer drill to drill 1-7/8" deep x 1/2" diameter anchor hole at marked locations using a 1/2" drill bit suitable for concrete drilling.

NOTE: Forms+Surfaces recommends starting holes with 3/16" diameter drill bit followed by 3/8" and finally 1/2" for maximum accuracy.




### 3 Insert & set anchors

- Use compressed air and steel wire brush to clean each anchor hole.
- Insert 3/8"-16 x 1-1/2" anchor (a) into each anchor hole and use hammer to tap anchor tops flush with ground level.
- Use 1/4" punch and hammer to set anchors by driving down the center of each anchor until it stops.

# UNIVERSAL RECEPTACLE


SURFACE MOUNT INSTALLATION INSTRUCTIONS

## STEP BY STEP FOR ALL SURFACE MOUNTED UNIVERSAL RECEPTACLES (SECTION VIEW SHOWN)




### Position receptacle

- Position receptacle so that mounting holes lines up with anchors.



### Attach receptacle

- Slide 3/8" stainless steel lock washer (c), then 3/8" stainless steel flat washer (d) and 3/8" nylon flat washer (e) onto each 3/8"-16 x 3" button head cap bolt (b).
- Insert bolts into mounting holes in base and thread into anchors using 7/32" hex bit or key.



### Tighten bolts

- Tighten bolts until snug.
- Place liner(s) inside receptacle, then insert lid.